

SC-02 Splash Cowl Installation Instructions

Tool Required: 1/4" Nut Driver or Flat-Blade Screwdriver

1) For 1-inch shafts, stick the adhesive shim to the curved inside of the shaft bracket first. For 1-1/8" shafts, omit the shim.

2) Tilt the Cowl to one side and push it forward onto the shaft.

CAUTION - this takes some force.

Be sure the *upper* front half is *opposite* the bracket side as shown.

Tip: Heat Cowl in hot water for easier installation (makes the plastic softer).



3) After installation, the front of the Cowl can be straightened by bending if needed.

4) Install the band clamp just tight enough so the Cowl position can be adjusted by hand.

5) Position the Cowl 2-3 inches below the gunwale of the boat. Adjust as needed for the least splash while cruising. Tighten the clamp at the best position.

6) Optional: Fill the cut in the front of the Cowl with epoxy putty. Use tape underneath to prevent it from running. Sand or trim when cured.

